## QUANTUM STUDIO DOME ATTACHMENT SDX

**INSTRUCTIONS** 

The SDX accessory can be used with any Calcu-Light/Calcu-Flash meter. Mount it with the swivel head over the mark  $\Lambda$  on the instrument housing. (To mount on early models, remove the turret thumbscrew by prying off the screw retainer on the underside of the turret).

You must re-calibrate your meter by adding 6 numbers to the DIN film speed of the film you are using. If your film is rated in ASA, multiply ASA x 4, and set that in the ASA window.

The SDX should be used in the incident light mode, and the incident light pointer on the dials must be used. Many photographers find a studio dome to be more convenient to use compared to the standard incident turret. The swivel head can be turned to suit the situation so that the digital display and dials are always in view.

## NOTE:

On earlier model Calcu-Flash (not type S or II) you <u>must</u> use the PC cord when measuring flash with the SDX. It will not operate in the remote (cordless) mode.