



Omicron Flash/Video Ring Light – QF26 Introduction

!! WARNING -- DANGEROUS HIGH VOLTAGE !!

The Omicron Flash/Video Ring light contains dangerous high voltages within. For professional use only. Do not disassemble this equipment. In the event of physical damage immediately disconnect power and return the unit to Quantum for repair.

Omicron Ring Light QF26 is a versatile lighting appliance for both still and video image capture own. There are three configurations for employing Omicron Flash/Video Ring Light. Please see the separate instructions **A**, **B**, or **C**, as introduced below, for the type of operation you desire:

Flash / Video Alternate Operation

A Shoot TTL or Manual flash controlled by Qflash. Switch to video mode for cameras with video capture.

Flash / Video Simultaneous Operation

B In the midst of shooting a segment, snap still image with flash, and continue recording video. Great for pulling high-res candid images from action scenes.

Video-only Operation

C Power for Omicron comes directly from a Quantum Turbo 3 or Turbo Blade. The video illumination can be manually adjusted. Shoot up to 90 minutes with Turbo 3, or 25 minutes with Turbo Blade at full power, or longer at lower illumination.



Quantum Instruments Inc.
10 Commerce Drive, Hauppauge NY 11788-3968 USA
Tel: 1-631-656-7400 Fax: 1-631-656-7410
www.qtm.com

SPECIFICATIONS

Size:	9.25" x 8.25" x 1.5"
Weight:	1.1 lb.
Mounting:	¼-20 thread socket
Input:	330V DC (from Qflash or Quantum Turbo 3 and Turbo Blade)
Beam Angle:	120 degree total at ½ intensity
Dimming	0% - 100%
Color Temperature:	Daylight: 5000K

Flash Specifications (ISO 400)

f/5.6	1/60sec	2.5m / 8.5 ft
f/8	1/60sec	1.8m / 6ft
f/11	1/60sec	1.2m / 4ft

Video Specifications

380 lux / 36 fc	1m / 3ft
170 lux / 16 fc	1.5m / 5 ft
100 lux / 9 fc	2m / 7 ft

Customer Service

Having any trouble using your Quantum product? We are here to help. Mail, call, fax, or email our Service Department: (631) 656-7400 or quanthelp@qtm.com

Service department
Quantum Instruments
10 Commerce Drive
Hauppauge, NY 11788
Tel: (631) 656-7400 Fax: (631) 656-7410
Website: www.qtm.com

Troubleshooting tips are available at www.qtm.com, Support, Customer Support, FAQ. If you suspect a malfunction or require adjustment, return the unit to us with an accurate description of the problem. Please be sure your problem is not caused by improper operating procedure or malfunctions in your other equipment. Send all equipment carefully packaged and insured to our address above.

An estimate of repair cost on out-of-warranty merchandise may be forwarded if you desire. This will require that we contact you for approval before proceeding and will delay return of your equipment. For fastest repair time, you may pre-approve repairs up to the limit of \$125 with your credit card. We will bill only for the actual costs up to the limit. If repair costs exceed your pre-approval, we will contact you.

Paying by check will delay the repair until the check clears (up to 15 days). payment by money order is acceptable.

Normal repair time is 10 – 15 business days. For expedited service, contact our Service Department.

Summary:

- Ship via UPS, Parcel Post, or other carrier, insured.
- Give a clear, detailed description of the problem.
- Give your mailing address and daytime phone number, fax #, and/or email.
- For warranty repairs include a copy of the receipt.

In addition, for out-of-warranty repairs with pre-approval:

- Provide your Visa, MasterCharge, or American Express card # and expiration date.
- Give us authority to charge costs up to \$125.00.
- Provide your billing address.

Note: Please do not e-mail your credit card information.

Limited Warranty

Quantum products have a 1 year limited warranty. Please refer to the Limited Warranty card for complete details, conditions, and terms.