

# QUANTUM COLOR GEL PACK QF66

## INSTRUCTIONS

Assortment of 7 Hi-Temp color gels for use with Quantum Qflash.

Use with Quantum Filter Kits:

QF64-Diffusing UV filter kit (included with Qflash). Diffusing filters will give an f/stop reduction.

QF65-Clear UV filter kit.

To add a color gel, remove the two filters from the retaining ring.

Insert the color gel between the two filters.

Insert the filter assembly into the retaining ring. Snap the retaining ring onto the reflector.

Packaged in order of color.

<b>PART NO. ROSCOLUX</b>	<b>COLOR</b>	<b>GENERAL USAGE</b>	<b>DENSITY (f/stop reduction)</b>
02	Bastard Amber	Warm Suntan skin tones	2/3 f/stop
08	Pale Gold	Slight warming effect	1/2 f/stop
12	Straw Yellow	Special effects	1 f/stop
20	Medium Amber	Simulates light from fire or sunset	2 1/2 f/stop
26	Light Red	Special effects	4 1/2 f/stop
80	Primary Blue	Special effects	2/3 f/stop
89	Moss Green	Special effects	1/2 f/stop

Different colors may be achieved by stacking the gels.

