

# QUANTUM POWER CABLE ML

## INSTRUCTIONS

---

The Quantum Power cable ML was specifically designed to provide power from the Quantum Battery 1 (or 1+) to the Polaroid Miniportrait's built in flash. Attached to one end of this cable is Quantum's Gripper plug. An important feature of this plug is that it can be locked onto the battery!

### HOW TO USE:

1. Insert the black colored plug into the power input jack on the miniportrait 203/403. The opposite end of the cable has the Quantum Gripper plug.
2. Before inserting the gripper plug into the Quantum Battery, loosen the shell until the locking fingers just start to become hidden under the shell. Insert the plug into the battery output jack until it is firmly seated. If you do not loosen the shell first, the plug will be difficult to insert into the battery (Fig. 1)
3. While holding the plug body, tighten the shell. It is not necessary to over-tighten the plug. Once you begin to feel resistance when tightening, you'll only need to tighten it 1/8 of a turn more to lock the plug onto the Quantum Battery. (Fig. 2)
4. To release the plug, loosen the shell about one turn and the plug can be disconnected from the battery.

